

SAFETY GUIDE

SAFETY

1. Never use bare wires and conductors for electricity extensions.
2. Always use proper plugs and switches.
3. Do not use electricity cables for hanging clothes.
4. Always use automatic voltage regulator with delayed start for deep freezers, refrigerator and televisions etc.
5. Always use proper capacitors MCBs (Miniature Circuit Breakers) with air-conditioners.
6. Do not touch metallic parts of the washing machine, electric motors and pedestal fans without removing electricity connections.
7. Use proper size fuses at each stage.

CONSERVATION OF ELECTRICITY

1. Always cut down unwanted switch off lights, machinery and other electrical appliances when not in use.
2. Use florescent lamps and mercury vapor lamps in place of conventional electric lamps.
3. Use proper size capacitors for fans, motors i.e. inductive loading.